

(2011 RocknRoller® Multi-Cart® Wheel Replacement Tip)

Replacing Bushings & Roller Bearings In Multi-Cart® Wheels (10"x3", 8"x2.5", 8"x2.0")

Models manufactured between 2000 and 2008 used a 20mm axel. After 2008 pneumatic wheels and solid wheels were made to fit a 19mm axel. If your replacement wheel fits tight on the axel and doesn't turn freely do the following procedure:



Gently pry the bushings out of the old wheel and new wheel as shown with a rounded rod-shaped tool (its easy). Press the old bushings into the new wheel hub and install wheel on axel. (We recommend putting a little axel grease on the bearings). The wheel should now turn easily on the axel.